Roll Up Piano RP-61

User manual

00022626
Version 01/2012

Main Features

- 61 Keys (C2~C7) Standard piano keyboard
- 128 Tones, 100 Rhythms and 12 Demo Song
- 3 digital display
- Special sound effect: Sustain
- 3 learning modes
- Recording/playback

Operation Steps

(1) Place the Roll-up Piano 61K-III HG on a flat surface. Unfold the keyboard carefully. Do not place the piano in rugged or dusty areas, it may damage the product functions.

(2) Slide out the left part of control panel which is a build-in speaker and place it on the other end of the roll-up piano. Do not force it while placing.

(3) Use only compatible adapter when playing roll-up Piano. Remove the batteries when plugging in with an adapter.

(4) Insert the batteries correctly if you choose to use them (instead of an adapter). Exhausted batteries should be removed from the case and if there's any leaking, clean the case with soft and dry cloth immediately before insert new batteries. Do not mix old and new batteries.

(5) Press "ON-OFF" to switch on the piano and the LED display will light up. The start-up mode is Tone 0 (Acoustic Grand Piano). Use ▲▼ to select the tone. Volume is set at level 005 and use VOLUME + or – to make adjustment.

(6) Please roll-up the keyboard properly (printed side up) and place it into the carry-bag after use.

Functions

***Keyboard function:**

61 keyboards, range fromC2~C7

10 level of volume

***Volume key**

Press VOLUME "+" or "-" to adjust the volume

***Tone function:**

128 tones (Please refer to the TONE list for more details)

Press “TONES” key to select the tone corresponding to the LED display.

Start-up mode is Tone 0, display will show 001. Then press ▲▼ key to select. You are able to select the tone while playing demo songs or in the learning mode.

***Rhythm function:**

100 rhythms (Please refer to the RHYTHM list for more details)

Press “RHYTHMS” key to turn on the rhythm option, and use ▲▼ to choose a rhythm preference. Then press “RHYTHMS START” or “STOP” key to start or stop your rhythm selection.

***DEMO function:**

30 demo songs (Please refer to the DEMO SONG list for more details)

Press “DEMO” key and the LED display will show on 001, use ▲▼ to choose a song preference. Then press “RHYTHMS START” or “STOP” key to start or stop your song selection.

*▲▼ **key**：

Press to select TONE, RHYTHM or DEMO SONGS.

***Special effect: sustain**

To control sustain with the sustain pedal (optional).

Note: not available for demo songs.

***Recording:**

Maximum 88 notes recordable.

Press “REC” to enter the recording mode.

Press “PLAY” and it will play the latest recording.

Press ”REC” or “STOP” to end recoding.

***Learning mode:**

Select a demo song from “DEMO”

Press “LEARN” to enter the learning mode and press again for learning mode 2 or learning mode 3.

Press “DEMO” or “STOP” to end learning mode.

A) Learning mode 1
   Playback of the selected song allows the learner to play the melody by pressing any key using the correct timing.
B) Learning mode 2
   Stops the playback of selected song if the learner can’t find the right note.
C) Learning mode 3
   Plays the accompaniment only.

In Addition: This product can be connected to external amplifiers/stereo and headsets.

***Cautions:**

1) When the unit is not being used, it is recommended that you remove all batteries from the battery compartment. This will safeguard against damages to the piano from battery leakage.
2) When using the adaptor, make sure that the batteries are removed.
3) If you are using the piano by means of an electrical outlet, always switch off the piano and remove the adapter from the main after use.
4) Keep the keyboard level when in use. Place uneven surface or move the keyboard around while playing. This may damage the functions.
5) Do not tamper with the wiring of this product with a cutter or other sharp tools. It may damage the keyboard functions.
6) When rolling up the keyboard after use, do not roll it too tight.
7) Do not pull or twist the body or keyboard.
8) Do not place the piano near areas with strong electric waves. The waves may affect and damage the product functions.
9) Do not separate any of the piano’s parts.
10) Do not use the piano in a wet or dusty area.
11) Avoid usage and storage in high temperature or high humidity. High temperature and moisture may cause the product malfunction.

TONE

No	Name of Instruments
0	Acoustic Grand Piano
1	Bright Acoustic Piano
2	Electric Grand Piano
3	Honky-tonk Piano
4	Rhodes Piano
5	Chorused Piano
6	Harpsichord
7	Clavi
8	Celesta
9	Glockenspiel
10	Music Box
11	Vibraphone
12	Marimba
13	Xylophone
14	Tubular Bells
15	Dulcimer
16	Hammond Organ
17	Percussive Organ
18	Rock Organ
19	Church Organ
20	Reed Organ
21	Accordion
22	Harmonica
23	Tango Accordion
24	Acoustic Guitar (Nylon)
25	Acoustic Guitar (Steel)
26	Electric Guitar (Jazz)
27	Electric Guitar (Clean)
28	Electric Guitar (Muted)
29	Overdriven Guitar
30	Distortion Guitar
31	Guitar Harmonics
32	Acoustic Bass
33	Electric Bass (Finger)
34	Electric Bass (Pick)

RHYTHM

No.	Name of Rhythm
00	Soul 1
01	Soul 2
02	Soul 3
03	Soul 4
04	Slow Soul 1
05	Slow Soul 2
06	Powerful Soul 1
07	Powerful Soul 2
08	Powerful Soul 3
09	Compaction soul 1
10	Compaction soul 2
11	Compaction soul 3
12	Euro Soul
13	AOR 1
14	AOR 2
15	16 Beat
16	16 Ballad
17	Pop Dance 1
18	Pop Dance 2
19	Pop Dance 3
20	Shuffle 1
21	Shuffle 2
22	8 Shuffle
23	Hard Rock
24	Show Rock
25	Blues
26	Twist
27	Hard 3 Beat
28	Love Ballad 1
29	Love Ballad 2
30	Love Ballad 3
31	Euro Beat
32	House 1
33	House 2
34	Swing Beat

35	Fretless Bass
36	Slap Bass 1
37	Slap Bass 2
38	Synth Bass 1
39	Synth Bass 2
40	Violin
41	Viola
42	Cello
43	Contrabass
44	Tremolo Strings
45	Pizzicato Strings
46	Orchestral Harp
47	Timpani
48	String Ensemble 1
49	String Ensemble 2
50	Synth Strings 1
51	Synth Strings 2
52	Choir Aahs
53	Voice Oohs
54	Synth Voice
55	Orchestra Hit
56	Trumpet
57	Trombone
58	Tuba
59	Muted Trumpet
60	French Horn
61	Brass Section
62	Synth Brass 1
63	Synth Brass 2
64	Soprano Sax
65	Alto Sax
66	Tenor Sax
67	Baritone Sax
68	Oboe
69	English Horn
70	Bassoon

35	Big Band 1
36	Big Band 2
37	Combo 1
38	Combo 2
39	Swing 1
40	Swing 2
41	Swing 3
42	Swing 4
43	Swing 5
44	Swing 6
45	Baiao
46	Bolero
47	Bossanova 1
48	Bossanova 2
49	Bossanova 3
50	Bossanova 4
51	Bossanova 5
52	Calypso
53	Habanera
54	Reggae 1
55	Reggae 2
56	Jorpo
57	Tango 1
58	Tango 2
59	Tango 3
60	Mambo 1
61	Mambo 2
62	Rumba 1
63	Rumba 2
64	Rumba 3
65	Rumba 4
66	Rumba 5
67	Bequine
68	Salsa
69	Merengue 1
70	Merengue 2

71	Clarinet
72	Piccolo
73	Flute
74	Recorder
75	Pan Flute
76	Blown Bottle
77	Shakuhach
78	Whistle
79	Ocarina
80	Lead 1 (square)
81	Lead 2 (Sawtooth)
82	Lead 3 (Calliope)
83	Lead 4 (Chiff)
84	Lead 5 (Charang)
85	Lead 6 (Voice)
86	Lead 7 (Fifths)
87	Lead 8 (Bass+Lead)
88	Pad 1 (New age)
89	Pad 2 (Warm)
90	Pad 3 (Polysynth)
91	Pad 4 (Choir)
92	Pad 5 (Bowed)
93	Pad 6 (Metallic)
94	Pad 7 (Halo)
95	Pad 8 (Sweep)
96	FX 1 (Rain)
97	FX 2 (Soundtrack)
98	FX 3 (Crystal)
99	FX 4 (Atmosphere)
100	FX 5 (Brightness)
101	FX 6 (Goblins)
102	FX 7 (Echoes)
103	FX 8 (Sci-Fi)
104	Sitar
105	Banjo
106	Shamisen

71	Vallenato
72	Plena
73	Lambada
74	Bachata
75	Samba
76	Pop Shamba 1
77	Pop Shamba 2
78	Jazz Samba
79	March 1
80	March 2
81	March 3
82	Polka 1
83	Polka 2
84	Polka 3
85	C & W 1
86	C & W 2
87	Bluegrass
88	Country 1
89	Country 2
90	Middle East
91	China 1
92	China 2
93	China 3
94	Thailand
95	Waltz 1
96	Waltz 2
97	Waltz 3
98	Jazz Waltz
99	Country Waltz

107	Koto
108	Kalimba
109	Bag Pipe
110	Fiddle
111	Shanai
112	Tinkle Bell
113	Agogo
114	Steel Drums
115	Woodblock
116	Taiko Drum
117	Melodic Tom
118	Synth Drum
119	Reverse Cymbal
120	Guitar Fret Noise
121	Breath Noise
122	Seashore
123	Bird Tweet
124	Telephone Ring
125	Helicopter
126	Applause
127	Gunshot

DEMO SONG

No	Name of Demo Song
0	For Alice
01	Turkey March
02	Susanna
03	Fantaisie Impromptu
04	Canon
05	Thorntree
06	Meacham American Patrol
07	Red River Valley
08	Russia Dance
09	Katyusha
10	Radetzky March
11	Spanish bullfighter